

PROGRAMMING YOUR REMOTE



1 Turn on your TV.

2 With your Hartelco remote, press the TV key.

3 Press and hold setup for 3 seconds. You'll see 2 red flashes on the TV key.

4 Enter this key sequence: 9, 9, 1. Then press the Channel+ key until the TV powers off. Press the SETUP key to save.

5 Press the TV key. Then press and hold setup for 3 seconds. You'll see 2 red flashes on the TV key.

6 Enter this key sequence, 9, 7, 2, Channel + .

You'll see 2 red flashes on the TV key when completing the programming sequence.